Link do produktu: https://www.pcomp3000.pl/bateria-pa5109u-1brs-do-toshiba-satellite-c50d-c55-p-13762.html

Bateria PA5109U-1BRS do Toshiba Satellite C50D C55

Cena brutto	**98,00 zł**
Cena netto	**79,67 zł**
Dostępność	**Zapytaj o dostępność**
Numer katalogowy	**46068533**
Kod producenta	**BA-PA5109**
Kod EAN	**5903624751158**
Producent	**Eneron**

Opis produktu

Kupując nasze baterie **masz pewność**, że są one w pełni sprawne i **świeżo wyprodukowane**.

Towar sprowadzamy **transportem lotniczym**, co w przypadku baterii jest bardzo istotne. Produkt taki **nie "leżakuje" na magazynie** i otrzymują Państwo towar **całkowicie nowy, sprawny, bez utraty pojemności.**

Bateria PA5109U-1BRS do Toshiba Satellite C50D C55

Markowa bateria ENERON to przede wszystkim:

▶ **Wysoka jakość** komponentów

▶ **Zestaw** niezbędnych **zabezpieczeń**

▶ Czas pracy - od **1,5h do 4h** (w zależności od sposobu użytkowania laptopa i sformatowania baterii),

▶ **Solidne** i precyzyjne **wykonanie**

Dane techniczne:

▶ Marka: **ENERON**

▶ Kod produktu: **BA-PA5109**

▶ Typ ogniw: **Litowo-jonowa**

▶ Pojemność: **4400mAh / 48Wh**

▶ Napięcie: **11.4V / 10.8V** (można stosować zamiennie)

▶ Liczba ogniw: **3**

▶ Zabezpieczenia: przed przegrzaniem, przed przeładowaniem, przed nadmiernym rozładowaniem

▶ Certyfikaty: **CE, RoHS**

▶ Czas pracy: **od 1,5h do 4h** - w zależności od trybu pracy oraz prawdiłowego sformatowania baterii (rozładować do 2%, po czym naładować na wyłączonym laptopie do 100%)

Cechy towaru:

▶ Kolor: Czarny

▶ Solidna konstrukcja

▶ Bezpiecznie zapakowana paczka

▶ Stan: nowa

▶ Wymagane zabezpieczenia i certyfikaty

Zamiennik baterii:

▶ PA5108U-1BRS

▶ PA5109U-1BRS

▶ PA5110U-1BRS

▶ PABAS271

▶ PABAS272

▶ PABAS273

Bateria pasuje do laptopów takich jak:

Toshiba Satellite C50, Toshiba Satellite C50-A, Toshiba Satellite C50-A-109, Toshiba Satellite C50-A-10D, Toshiba Satellite C50-A-11H, Toshiba Satellite C50-A-11J, Toshiba Satellite C50-A-12M, Toshiba Satellite C50-A-12T, Toshiba Satellite C50-A-146, Toshiba Satellite C50-A-149, Toshiba Satellite C50-A-14E, Toshiba Satellite C50-A-14V, Toshiba Satellite C50-A-14W, Toshiba Satellite C50-A-14X, Toshiba Satellite C50-A-15G, Toshiba Satellite C50-A-15L, Toshiba Satellite C50-A-176, Toshiba Satellite C50-A-179, Toshiba Satellite C50-A-180, Toshiba Satellite C50-A-182, Toshiba Satellite C50-A-185, Toshiba Satellite C50-A-19T, Toshiba Satellite C50-A-19U, Toshiba Satellite C50-A-1C6, Toshiba Satellite C50-A-1CK, Toshiba Satellite C50-A-1DN, Toshiba Satellite C50-A-1DU, Toshiba Satellite C50-A-1DV, Toshiba Satellite

C50-A-1F1, Toshiba Satellite C50-A-1FT, Toshiba Satellite C50-A-1FU, Toshiba Satellite C50-A-1G0, Toshiba Satellite C50-A-1G3, Toshiba Satellite C50-A-1G6, Toshiba Satellite C50-A-1HF, Toshiba Satellite C50-A-1JM, Toshiba Satellite C50-A-1JN, Toshiba Satellite C50-A-1JP, Toshiba Satellite C50-A-1JQ, Toshiba Satellite C50-A-1JR, Toshiba Satellite C50-A-1JT, Toshiba Satellite C50-A-1JU, Toshiba Satellite C50-A-1KQ, Toshiba Satellite C50-A-1KZ, Toshiba Satellite C50-A-1LF, Toshiba Satellite C50-A-K9K, Toshiba Satellite C50-A-L2W, Toshiba Satellite C50D, Toshiba Satellite C50D-A, Toshiba Satellite C50D-A-10E, Toshiba Satellite C50D-A-10M, Toshiba Satellite C50D-A-10T, Toshiba Satellite C50D-A-10U, Toshiba Satellite C50D-A-10W, Toshiba Satellite C50D-A-10Z, Toshiba Satellite C50D-A-11G, Toshiba Satellite C50D-A-11L, Toshiba Satellite C50D-A-11Q, Toshiba Satellite C50D-A-126, Toshiba Satellite C50D-A-131, Toshiba Satellite C50D-A-133, Toshiba Satellite C50D-A-134, Toshiba Satellite C50D-A-136, Toshiba Satellite C50D-A-138, Toshiba Satellite C50D-A-139, Toshiba Satellite C50D-A-13E, Toshiba Satellite C50D-A-13G, Toshiba Satellite C50D-A-13H, Toshiba Satellite C50D-A-149, Toshiba Satellite C50D-A-K8K, Toshiba Satellite C50t-A, Toshiba Satellite C50t-A-10K, Toshiba Satellite C50t-A-10T, Toshiba Satellite C50t-A-10Z, Toshiba Satellite C55, Toshiba Satellite C55-A, Toshiba Satellite C55-A-100, Toshiba Satellite C55-A-101, Toshiba Satellite C55-A-109, Toshiba Satellite C55-A-10C, Toshiba Satellite C55-A-10M, Toshiba Satellite C55-A-10N, Toshiba Satellite C55-A-10P, Toshiba Satellite C55-A-10T, Toshiba Satellite C55-A-10U, Toshiba Satellite C55-A-11L, Toshiba Satellite C55-A-12C, Toshiba Satellite C55-A-12D, Toshiba Satellite C55-A-136, Toshiba Satellite C55-A-138, Toshiba Satellite C55-A-140, Toshiba Satellite C55-A-141, Toshiba Satellite C55-A-145, Toshiba Satellite C55-A-146, Toshiba Satellite C55-A-149, Toshiba Satellite C55-A-14F, Toshiba Satellite C55-A-157, Toshiba Satellite C55-A-158, Toshiba Satellite C55-A-15R, Toshiba Satellite C55-A-15W, Toshiba Satellite C55-A-165, Toshiba Satellite C55-A-16Z, Toshiba Satellite C55-A-181, Toshiba Satellite C55-A-184, Toshiba Satellite C55-A-186, Toshiba Satellite C55-A-195, Toshiba Satellite C55-A-199, Toshiba Satellite C55-A-19N, Toshiba Satellite C55-A-1CW, Toshiba Satellite C55-A-1CX, Toshiba Satellite C55-A-1DC, Toshiba Satellite C55-A-1E3, Toshiba Satellite C55-A-1EH, Toshiba Satellite C55-A-1F5, Toshiba Satellite C55-A-1FN, Toshiba Satellite C55-A-1FP, Toshiba Satellite C55-A-1G0, Toshiba Satellite C55-A-1G2, Toshiba Satellite C55-A-1GJ, Toshiba Satellite C55-A-1GK, Toshiba Satellite C55-A-1GT, Toshiba Satellite C55-A-1GU, Toshiba Satellite C55-A-1H9, Toshiba Satellite C55-A-1HC, Toshiba Satellite C55-A-1HE, Toshiba Satellite C55-A-1HL, Toshiba Satellite C55-A-1HM, Toshiba Satellite C55-A-1HN, Toshiba Satellite C55-A-1JJ, Toshiba Satellite C55-A-1JL, Toshiba Satellite C55-A-1JP, Toshiba Satellite C55-A-1JQ, Toshiba Satellite C55-A-1JX, Toshiba Satellite C55-A-1K4, Toshiba Satellite C55-A-1K7, Toshiba Satellite C55-A-1KG, Toshiba Satellite C55-A-1KU, Toshiba Satellite C55-A-1L0, Toshiba Satellite C55-A-1MW, Toshiba Satellite C55-A-1N0, Toshiba Satellite C55-A-1N1, Toshiba Satellite C55-A-1ND, Toshiba Satellite C55-A-1NK, Toshiba Satellite C55-A-1NN, Toshiba Satellite C55-A-1NV, Toshiba Satellite C55-A-1RH, Toshiba Satellite C55-A-1RL, Toshiba Satellite C55-A-1RM, Toshiba Satellite C55-A-1RN, Toshiba Satellite C55-A-1RV, Toshiba Satellite C55-A-1TK, Toshiba Satellite C55-A-1U3, Toshiba Satellite C55-A-1UC, Toshiba Satellite C55-A-1V3, Toshiba Satellite C55-A5220, Toshiba Satellite C55-A5221, Toshiba Satellite C55-A5242, Toshiba Satellite C55-A5243, Toshiba Satellite C55-A5246NR, Toshiba Satellite C55-A5281, Toshiba Satellite C55-A5282, Toshiba Satellite C55-A5285, Toshiba Satellite C55-A5286, Toshiba Satellite C55-A5298, Toshiba Satellite C55-A5300, Toshiba Satellite C55-A5302, Toshiba Satellite C55D, Toshiba Satellite C55D-A, Toshiba Satellite C55D-A-10G, Toshiba Satellite C55D-A-10V, Toshiba Satellite C55D-A-118, Toshiba Satellite C55D-A-11L, Toshiba Satellite C55D-A-12N, Toshiba Satellite C55D-A-13G, Toshiba Satellite C55D-A-13Q, Toshiba Satellite C55D-A-13U, Toshiba Satellite C55D-A-140, Toshiba Satellite C55D-A-147, Toshiba Satellite C55D-A-15H, Toshiba Satellite C55D-A-15K, Toshiba Satellite C55Dt, Toshiba Satellite C55Dt-A, Toshiba Satellite C55Dt-A5241, Toshiba Satellite C55Dt-A5244, Toshiba Satellite C55t, Toshiba Satellite C55t-A, Toshiba Satellite C55t-A-10K, Toshiba Satellite C70, Toshiba Satellite C70-A, Toshiba Satellite C70-A-102, Toshiba Satellite C70-A-13D, Toshiba Satellite C70-A-13V, Toshiba Satellite C70-A-14C, Toshiba Satellite C70-A-14Z, Toshiba Satellite C70-A-16J, Toshiba Satellite C70-A-16N, Toshiba Satellite C70-B, Toshiba Satellite C70-B-20W, Toshiba Satellite C70-B-212, Toshiba Satellite C70-B-216, Toshiba Satellite C70-B-31G, Toshiba Satellite C70-B-31P, Toshiba Satellite C70-B-33K, Toshiba Satellite C70-B-33L, Toshiba Satellite C70-B-35E, Toshiba Satellite C70-B-35L, Toshiba Satellite C70-B-360, Toshiba Satellite C70D, Toshiba Satellite C70D-A, Toshiba Satellite C70D-A-107, Toshiba Satellite C70D-A-108, Toshiba Satellite C70D-A-10U, Toshiba Satellite C70D-A-11C, Toshiba Satellite C70D-A-11D, Toshiba Satellite C70D-A-11E, Toshiba Satellite C70D-A-11H, Toshiba Satellite C70D-A-L1S, Toshiba Satellite C70D-B, Toshiba Satellite C70D-B-107, Toshiba Satellite C70D-B-10C, Toshiba Satellite C70D-B-10E, Toshiba Satellite C70D-B-10U, Toshiba Satellite C70D-B-10X, Toshiba Satellite C70D-B-110, Toshiba Satellite C70D-B-11K, Toshiba Satellite C70D-B-300, Toshiba Satellite C70D-B-302, Toshiba Satellite C70D-B-306, Toshiba Satellite C70D-B-314, Toshiba Satellite C70D-B-316, Toshiba Satellite C70D-B-32G, Toshiba Satellite C70D-B-33K, Toshiba Satellite C75, Toshiba Satellite C75-A, Toshiba Satellite C75-A-100, Toshiba Satellite C75-A-101, Toshiba Satellite C75-A-102, Toshiba Satellite C75-A-10J, Toshiba Satellite C75-A-10P, Toshiba Satellite C75-A-11J, Toshiba Satellite C75-A-129, Toshiba Satellite C75-A-12D, Toshiba Satellite C75-A-12E, Toshiba Satellite C75-A-12R, Toshiba Satellite C75-A-12V, Toshiba Satellite C75-A-13C, Toshiba Satellite C75-A-13P, Toshiba Satellite C75-A-13R, Toshiba Satellite C75-A-140, Toshiba Satellite C75-A-143, Toshiba Satellite C75-A-144, Toshiba Satellite C75-A-146, Toshiba Satellite C75-A-14C, Toshiba Satellite C75-A-14D, Toshiba Satellite C75-A7266, Toshiba Satellite C75D, Toshiba Satellite C75D-A, Toshiba Satellite C75D-A-10C, Toshiba Satellite C75D-A7213, Toshiba Satellite C75D-A7223, Toshiba Satellite C75D-A7226, Toshiba Satellite C75D-A7286, Toshiba Satellite L70, Toshiba Satellite L70-A, Toshiba Satellite L70-A-10K, Toshiba Satellite L70-A-138, Toshiba Satellite L70-A-139, Toshiba Satellite L70-B, Toshiba Satellite L70-B-10J, Toshiba Satellite L70-B-10L, Toshiba Satellite L70-B-10M, Toshiba Satellite L70-B-10P, Toshiba Satellite L70-B-10R, Toshiba Satellite L70-B-10W, Toshiba Satellite L70-B-10X, Toshiba Satellite L70-B-111, Toshiba Satellite L70-B-113, Toshiba Satellite L70-B-119, Toshiba Satellite L70-B-125, Toshiba Satellite L70-B-130, Toshiba Satellite L70-B-132, Toshiba Satellite L70-B-13G, Toshiba Satellite L70-B-13H, Toshiba Satellite L70-B-145, Toshiba Satellite L70-B-14Q, Toshiba Satellite L70-B-14Z, Toshiba Satellite L70-B-153, Toshiba Satellite L70-B-155, Toshiba Satellite P70-B-101, Toshiba Satellite P70-B-102, Toshiba Satellite Pro A50, Toshiba Satellite Pro A50-A, Toshiba Satellite Pro A50-A-10L, Toshiba Satellite Pro A50-A-10V, Toshiba Satellite Pro A50-A-110, Toshiba Satellite Pro C50, Toshiba Satellite Pro C50-A, Toshiba Satellite Pro C50-A-137, Toshiba Satellite Pro C50-A-13T, Toshiba Satellite Pro C50-A-143, Toshiba Satellite Pro C50-A-153, Toshiba Satellite Pro C50-A-154, Toshiba Satellite Pro C50-A-15H, Toshiba Satellite Pro C50-A-15Q, Toshiba Satellite Pro C50-A-165, Toshiba Satellite Pro C50-A-166, Toshiba Satellite Pro C50-A-17H, Toshiba Satellite Pro C50-A-1C8, Toshiba Satellite Pro C50-A-1C9, Toshiba Satellite Pro C50-A-1E0, Toshiba Satellite Pro C50-A-1E1, Toshiba Satellite Pro C50-A-1E2, Toshiba Satellite Pro C50-A-1E6, Toshiba Satellite Pro C50-A-1EK, Toshiba Satellite

Pro C50-A-1EP, Toshiba Satellite Pro C50-A-1EV, Toshiba Satellite Pro C50-A-1FD, Toshiba Satellite Pro C50-A-1FE, Toshiba Satellite Pro C50-A-1HP, Toshiba Satellite Pro C50-A-1HR, Toshiba Satellite Pro C50-A-1K9, Toshiba Satellite Pro C50-A-1KD, Toshiba Satellite Pro C50-A-1KF, Toshiba Satellite Pro C50-A-1KH, Toshiba Satellite Pro C50-A-1KJ, Toshiba Satellite Pro C50-A-1KV, Toshiba Satellite Pro C50-A-1L6, Toshiba Satellite Pro C50-A-1L7, Toshiba Satellite Pro C50-A-1LT, Toshiba Satellite Pro C50-A-1LU, Toshiba Satellite Pro C50D, Toshiba Satellite Pro C50D-A, Toshiba Satellite Pro C50D-A-145, Toshiba Satellite Pro C70, Toshiba Satellite Pro C70-A, Toshiba Satellite Pro C70-A-12D, Toshiba Satellite Pro C70-A-12F, Toshiba Satellite Pro C70-A-12H, Toshiba Satellite Pro C70-A-13Q, Toshiba Satellite Pro C70-A-13R, Toshiba Satellite Pro C70-A-13Z, Toshiba Satellite Pro C70-A-140, Toshiba Satellite Pro C70-A-148, Toshiba Satellite Pro C70-A-152, Toshiba Satellite Pro C70-B-10M, Toshiba Satellite Pro C70-B-10N, Toshiba Satellite Pro C70-B-111, Toshiba Satellite Pro C70-B-125, Toshiba Satellite Pro C70-B-12C, Toshiba Satellite Pro C70-B-12Z, Toshiba Satellite Pro C70-B-133, Toshiba Satellite Pro C70-B-135, Toshiba Satellite Pro C70-B-14H, Toshiba Satellite Pro C70-B-14J, Toshiba Satellite Pro C70-B-14Z, Toshiba Satellite Pro C70-B-301, Toshiba Satellite Pro C70-B-34U, Toshiba Satellite Pro C70-B-34V, Toshiba Satellite Pro L70, Toshiba Satellite Pro L70-A, Toshiba Satellite Pro L70-A-11T, Toshiba Satellite Pro L70-A-137, Toshiba Satellite Pro L70-A-142, Toshiba Satellite S70, Toshiba Satellite S70-A, Toshiba Satellite S70-A-10C, Toshiba Satellite S70-A-10F, Toshiba Satellite S70-B-10N, Toshiba Satellite S70-B-10U, Toshiba Satellite S70-B-10V, Toshiba Satellite S70-B-10W, Toshiba Satellite S70-B-10X, Toshiba Satellite S70-B-10Z, Toshiba Satellite S70-B-110, Toshiba Satellite S70-B-112, Toshiba Satellite S70-B-114, Toshiba Satellite S70-B-117, Toshiba Satellite S70-B-11D, Toshiba Satellite S70-B-11J, Toshiba Satellite S70t, Toshiba Satellite S70t-A, Toshiba Satellite S70t-A-105, Toshiba Satellite S70t-A-106, Toshiba Satellite S75, Toshiba Satellite S75-A7111, Toshiba Satellite S75-A7221, Toshiba Satellite S75-B7121, Toshiba Satellite S75-B7122, Toshiba Satellite S75-B7218, Toshiba Satellite S75-B7314, Toshiba Satellite S75-B7316, Toshiba Satellite S75D, Toshiba Satellite S75D-A7272, Toshiba Satellite S75D-A7346, Toshiba Satellite S75Dt, Toshiba Satellite S75Dt-A7330, Toshiba Tecra A50, Toshiba Tecra A50-A-10X, Toshiba Tecra A50-A-12C, Toshiba Tecra A50-A-12P, Toshiba Tecra A50-A-12Z, Toshiba Tecra A50-A-13C, Toshiba Tecra A50-A-13W, Toshiba Tecra A50-A-140, Toshiba Tecra A50-A-150, Toshiba Tecra A50-A-151, Toshiba Tecra A50-A-152, Toshiba Tecra A50-A-19N, Toshiba Tecra A50-A-1C3, Toshiba Tecra A50-A-1EF, Toshiba Tecra A50-A-1EH, Toshiba Tecra A50-A-1EJ, Toshiba vSatellite L70-A-10G